



Model number
 3 or 4 digits

Notes:

1. Part numbers will contain no spaces and only one dash between the pin count and options.
2. Part number digits which are not applicable to a specific part will be left out and not replaced by any placeholder.
3. Sample tubes which contain more than one model will use the series number in the model number section. For example: a sample tube of 1200P, 1203P and 1206P parts will be numbered 1200P08-UQ.
4. The first 4 or 5 digits (up to the package style) will typically be printed on the IC.